NovaShine® Sparkling Silver

Sparkling Clear Nail Enamel

Sample Formulation

Sparkling Clear Nail Enamel

INCI Name A	% W/W	
Nitrocellulose	15,00	
Isopropyl Alcohol	8,00	
Polyester Resin	9,00	
Dibutyl Phthalate	5,00	
Camphor	1,70	
Stearylalkomium Bentonite	0,90	
NovaShine [®] F1-0401	2,00	
В		
Thinners		
Ethyl Acetate	19,40	

39,00

Procedure

n-Butyl Acetate


- 1. Mix Phase A until uniform
- 2. Mix phase B until uniform
- 3. Add phase B and phase A and mix until uniform

Producer

Brazel Technology GmbH Otto-Hahn Str. 17 D-73230 Kirchheim-Teck E-Mail: support@brazel.com www.brazel.com

We provide information and advice to our customers on application technologies and regulatory matters to the best of our knowledge and ability, but without obligation or libility. Existing laws and regulations are to be observed in all cases by our customers. This also applies in respect to any rights of third parties. Our information and advice do not releive our customers of their own responsibility for checking the suitability of our products for the envisaged purpose.

Issue 111/06



Brazel Technology Advanced Materials