

## Sparkling Lip Stick

### Sample Formulation

Sparkling Lip Stick

INCI Name	% W/W
-----------	-------

#### A

White Ozokerite Wax	10,50
Polyethylene	5,00
Octyldodecyl Stearate	13,00
Diisopropyl Adipate	2,00
Isoceryl Stearoyl Stearate	14,70
Butyrospermum Parkii (Shea Butter)	4,00
C12-15 Alkyl lactate	11,00
Hydrogenated Polyisobutene	5,00
VP/Eicosene Copolymer	5,00
VP/Hexadecene Copolymer	5,00
Vitamine E Acetate	0,20
Vitamine A Palpitate	0,10

#### B

Paraben	0,40
---------	------

#### C

Isocetyl Stearoyl Stearate	3,07
Tricontanyl PVP	0,06

#### D

Mica	5,00
Bismuth Oxychloride	3,00
<b>NovaShine® F1-0401</b>	<b>10,00</b>
Tricontanyl PVP	0,06

#### Procedure

1. Prepare phase C
2. Melt phase A, heat to 90-95 °C,  
mix until uniform and cool the batch to 82 - 85 °C
3. Add Phase B, mix until uniform
4. Add phase C and mix approximately 30 minutes
5. Add Phase D, mix slowly until uniform ( prevent aerating the batch)
6. Pour the samples at 82 - 85 °

#### Producer

Brazel Technology GmbH  
Otto-Hahn Str.17  
D-73230 Kirchheim-Teck  
E-Mail: support@brazel.com  
www.brazel.com

We provide information and advice to our customers on application technologies and regulatory matters to the best of our knowledge and ability, but without obligation or liability. Existing laws and regulations are to be observed in all cases by our customers. This also applies in respect to any rights of third parties. Our information and advice do not relieve our customers of their own responsibility for checking the suitability of our products for the envisaged purpose.

Issue 111/06